



3009-XX

3009-18, 3009-1, 3009-05,
3009-30, 3009-55

NO RINSING REQUIRED

DEODORIZES, CLEANS AND TREATS AIR-CONDITIONING SYSTEMS FOR MAXIMUM EFFICIENCY

RETARDS FUTURE DIRT ACCUMULATION

ELIMINATES SLIME IN CONDENSATE AREAS

DANGER: CAUSES SEVERE SKIN BURNS AND EYE DAMAGE. KEEP OUT OF REACH OF CHILDREN. CONTENTS UNDER PRESSURE. SEE BACK PANEL FOR ADDITIONAL PRECAUTIONS. FOR PROFESSIONAL USE ONLY.

3009

DANGER: Causes severe skin burns and eye damage.

Do not breathe mist/vapors/spray. Wash face, hands, and any exposed skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection.

FIRST AID: IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable for breathing. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/Doctor.

Store locked up. Dispose of contents and container in accordance with all local, regional, and national regulations.

Contains [CAS#]: Sodium metasilicate [6834-92-0], dipropylene glycol monomethyl ether [34590-94-8].



North American Research Corp.

519 Huffines Blvd., Lewisville, TX 75056

800.527.7520 | 972.492.1800

Fax: 972.394.6755

Web: NarcoChem.com

info@narcochem.com



DIRECTIONS FOR USE:

(Window Units, Small Central Units)

1. Read entire label & **Safety Data Sheet** before use.
2. Dilute with up to 6 parts water.
3. Shut unit off.
4. Spray coil thoroughly using a coarse spray to avoid misting.
5. Wait 5 minutes and resume normal operation.
6. No rinsing is required when condensation is present. If condensation is not expected, rinse with water.

(Commercial Systems, Air Handling Units)

Dilute with up to 6 parts water before use. If possible leave air-flow on during application. Spray intake side of coil with coarse spray until saturated to the run off point. (Suction of system will cause complete coil penetration.) Refuse and contamination will drain as condensate. If it is not possible to leave air-flow on during application, spray coil thoroughly and turn air on immediately after application. If condensation is not expected, rinse with water.