

**9401, 9405, 9430, 9455** 

## **COOLING COIL ANTI-FOULANT**

## CONTINUOUSLY PROTECTS COILS FROM FOULING CAUSED BY AIRBORNE PARTICULATE AND OTHER CONTAMINANTS – FOR UP TO 2-3 YEARS


- ✓ Contains Preservatives That Protect It From Deterioration Caused By Mold And Bacterial Growth Common In Air Conditioning Units
- ✓ Eliminates Foul Odors At Their Source
- ✓ Improves Indoor Air Quality (IAQ)

**CAUTION:** KEEP OUT OF REACH OF CHILDREN. SEE SIDE PANELS FOR ADDITIONAL PRECAUTIONARY AND FIRST AID STATEMENTS

CAUTION: Splash goggles are recommended.

**FIRST AID:** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. If eye irritation develops or persists: Get medical advice/attention.IF INHALED: Remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER/doctor if you feel unwell.IF ON SKIN: Wash with plenty of soap and water. Take off contaminated clothing and wash it before reuse. If skin irritation occurs: Get medical advice/attention. IF SWALLOWED: Immediately call a POISON CENTER/doctor. Do NOT induce vomiting.

Contains [CAS]:Acrylic polymer(s) [non-hazardous], Dipropylene glycol methyl ether [34590-94-8].



519 Huffines Blvd., Lewisville, TX 75056 800.527.7520 | 972.492.1800 Fax: 972.394.6755 Web: NarcoChem.com info@narcochem.com



Read entire label and <u>S</u>afety <u>D</u>ata <u>S</u>heet before use. Use only according to directions. Shake well before use. For best results apply with a garden or hand type sprayer adjusted to a fine mist. Use enough STAY-CLEAN to dampen entire coil surface. Coil must be thoroughly cleaned and DRY before application. PRE-CLEAN is ideal for cleaning coil prior to treatment as it is manufactured to be compatible with STAY-CLEAN. Drying of coil can be accelerated by running the fan only. Allow at least 30 minutes for STAY-CLEAN to cure before putting system back on line. Clean spraying equipment with water.

## **DIRECTIONS FOR USE:**

- 1. Shake well before use
- 2. Clean and dry coil thoroughly.
- 3. If possible spray coil from intake side and leave air flow on to aid complete coil penetration. Use a fine mist and spray lightly to avoid bridging the coating between fins.
- 4. Allow at least 30 minutes cure time before putting system back on line.
- 5. STAY-CLEAN is a water based product. Keep it out of contactors, motors, etc.

